

The following are instructions on how to use NetDMX with GrandMA Dot2, if you are unable to connect using any other method.

A. Create a 'Microsoft Loopback Adapter' in Device Manager...

To install Microsoft Loopback Adapter :

- In the host operating system, right-click "My Computer", and then select "Properties" (Depending on the style of the start menu, My Computer may be located in the Start menu)
- In the System Properties dialog box (on the Hardware tab) click "Add Hardware Wizard"
- In the Add Hardware dialog box, click [Next]
- When the "Is the hardware connected?" dialog box appears, click "YES, I have already connected the hardware", and then click [Next]
- In the Installed hardware list, click "Add a new hardware device", and then click [Next]
- In the "What do you want the wizard to do?" list, click "Install the hardware that I manually select from a list (Advanced)", and then click [Next]
- In the Common hardware types list, click "Network adapters", and then click [Next]
- In the Manufacturer list, click "Microsoft"
- In the Network Adapter list, click "Microsoft Loopback Adapter", and then click [Next] twice.
- If a message about driver signing appears, click "Continue Anyway"
- In the Completing the Add Hardware Wizard dialog box, click [Finish], and then click [OK]

B) Open network settings assign an IP/ subnet in same ranges i.e 2.0.0.2, 255.255.255.0 (your subnet MUST match your NetDMX)

C) Assign the Nic in Dot2 to the Loopback, set the Network out to Art-Net

D) Open QLC+ go to input and output

E) Enable passthrough

F) Select input on the loopback

G) Select output to ethernet card

Technical Support

email : bob.lynas@btinternet.com or sales@smartshow.lighting